

PRODUCT: RR 601

Applications

- Commercial & Highway
- Thick/Heavy Slabs
- High/Heavy Traffic Areas

RR 601 Foam was developed to have an average reaction time and more spread to have more control when lifting larger slabs of concrete. This is the first HMI foam specifically for heavy load. Three times the density of the RR 201 this foam is specially designed for heavy lifting and high traffic areas. Exceeds typical specifications for DOT under-sealing and lifting projects.

RR 601

Density ASTM D1622		Open Cell Content ASTM D2856	
6.0-6.5	Closed Cell Content	89.7 ± 1.6%	
Compression Properties ASTM D1621		HMI Testing	
2207	Time at Reaction (mm:sec)	00:15	
145.7	Peak Exotherm (°F)	270	
6.7	Time at Peak Exotherm (mm:sec)	00:25	
193.6	Time at Tack Free (mm:sec)	00:23	
292.1	Time at Peak Expansion (mm:sec)	00:23	
16.4			
	Water Absorption ASTM D2842		
523	Absorption by Volume (%)	0.04	
5072			
138.4	Volume Change ASTM D	2126	
4.0	Change from Initial Volume (%)	+0.28	
138.4			
	Liquid Resin Density		
	•	re 9.4	
	RR A #Gallon at Room Temperature	10.3	
	RR 601B #/Gallon at 100° F	9.2	
	RR A #/Gallon at 100° F	10.2	
	2207 145.7 6.7 193.6 292.1 16.4 5072 138.4 4.0	D1621 Peak Exotherm (°F) 6.7 Time at Peak Exotherm (mm:sec) 193.6 Time at Tack Free (mm:sec) 292.1 Time at Peak Expansion (mm:sec) 16.4 Water Absorption ASTM Absorption by Volume (%) 5072 138.4 Volume Change ASTM D Change from Initial Volume (%) Liquid Resin Density RR 601B #Gallon at Room Temperature RR 601B #/Gallon at 100° F	

1025 E. Albert Drive Manitowoc, Wisconsin 54220

EQUIPMENT AND COMPONENT RATIOS:

The two part polyurethane process will give optimal performance when all systems are operating in correct sequence. Recirculate the material well before use. RR A (part A) is connected to the isocyanate pump with HMI Polyol (part B) connected to the resin/polyol pump. Part A and Part B must be mixed on a 1:1 ratio for designed reaction time, expansion rate, cure time, and density. It is recommended that this process be operated with a HMI Fusion Pro gun.

STORAGE OF CHEMICALS:

Store in original container protected from direct sunlight in a dry, cool and well-ventilated area, away from heat, sparks, open flame, strong oxidizers, radiation and other initiators. Keep container tightly closed and sealed until ready for use. Do not store above 100°F. Do not allow material to freeze; Condensation and moisture can cause the material to crystalize.

SAFE HANDLING OF LIQUID COMPONENTS:

Take skin, auditory, eye and respiratory safety precautions during material handling and installation. Avoid breathing vapors or spray mists for long periods of time. Avoid contact with eyes, skin, and clothing. In case of eye contact, gently flush eyes with large amounts of water for at least 15 minutes and get prompt medical attention. If chemicals contact with clothing and skin, remove contaminated clothing and launder. Flush skin with lukewarm water for at least 15 minutes and seek medical attention if irritation to skin occurs. For more information, refer to *Polyol Resin Blends Safety and Handling Guidelines* (Technical Bulletin AX228) issued by Alliance for the Polyurethanes Industry. Arlington, VA: American Plastics Council.

CAUTION:

If used incorrectly, the polyurethane foam may present a serious fire hazard. Part A and Part B mix to make foam that creates a chemical reaction which produces heat and fumes. While installing material, inject material, wait for expansion, wait to cool off, and then install additional material. DO NOT install additional material before this reaction is complete. Applying foams too thick in a single injection can build dangerously high temperatures inside the finished foam, which could lead to splitting, charring, or even spontaneous combustion. HMI recommends that thickness not exceed two inches for closed celled foams. If multiple passes are sprayed or injected, sufficient time must be allowed for the exothermic heat to dissipate before each additional injection is applied. The foam applicator/contractor engaged in the application or use of polyurethane material should be made aware of the combustibility of the foam and fire hazards it can present if misused or over applied. Proper precautions and safety measures should be utilized.